

## How to update firmware for SNMP Manager

1 · Run ViewPower Pro , choose “SNMP Manager” by clicking right button of the mouse. Refer to chart 1

EN




chart 1

1 · Click “Scan” button , fine and select the SNMP card IP address. Refer to chart 2




Chart 2

Step1: Click “Browse” button to choose program file. Refer to chart 3.




Chart 3

Step2: Click “Upgrade” button to execute upgrade action. Refer to chart 4.




Chart 4

Step3: When upgrade is complete, you may check the message in output window. Refer to chart 5.




Chart 5